


Bent Shaft Head Fitment & Assembly Details


Option A: Long Spindle

1. Remove original head from weedcutter (consult your owners manual for details).
2. Slide the Littl' Juey adapter onto spindle.
3. Attach the Littl' Juey base and spacer with the appropriate nut or bolt inside the base (add washer if necessary).
4. Tighten nut or bolt until secure.
5. Attach the Littl' Juey head with Littl' Juey Line Reload in the holes provided and tighten.



Option B: Short Spindle

1. Remove original head from weedcutter (consult your owners manual for details).
2. Attach the Littl' Juey base onto spindle with appropriate nut or bolt inside base.
3. Follow steps 4 & 5 as per Weedcutter Type A



Recommended Nylon:

- Littl' Juey 2.4mm Standard Line Reload



Please Note:
Safety equipment
must be worn
when operating
your weedcutter.

Littl' Juey
www.littljuey.com